

# DART SERVICE INSTRUCTION

TO AMEND INSTALLATION INSTRUCTIONS IIN-D206-642 REV. O AND  
INSTRUCTIONS FOR CONTINUED AIRWORTHINESS ICA-D206-642 REV. 4

REF FAA STC: SA00475SE

REF CANADIAN STC: SH98-4

REF EASA STC: EASA.IM.R.S.01320

## PROCEDURE:

FOR D206-642-113/-114 SKIDTUBE INSTALLATION KITS, IT HAS BEEN DETERMINED THAT AN5-10A (FWD) AND AN5-11A (AFT) BOLTS ARE MORE APPROPRIATE BOLT LENGTHS FOR ATTACHING THE SKIDTUBES TO THE CROSSTUBES THAN THE AN5-7A BOLTS PREVIOUSLY PROVIDED IN THE KITS.

### 4.2 206A/B LOW GEAR SKIDTUBES (WITH RUN-ON LANDING WEARPLATES) 32.12 206A/B LOW GEAR SKIDTUBES (WITH RUN-ON LANDING WEARPLATES)

ITEM	QTY. -113	QTY. -114	PART NUMBER	DESCRIPTION
			D206-642-113	SKIDTUBE INSTALLATION, LH
			D206-642-114	SKIDTUBE INSTALLATION, RH

#### IS:

13	4	4	AN5-10A	BOLT
14	4	4	AN5-11A	BOLT

#### WAS:

13	4	4	AN5-7A	BOLT
14	4	4	AN5-7A	BOLT

FOR FURTHER DETAILS REFER TO PAGE 22, DETAIL A OF IIN-D206-642 REV. O, OR PAGE 30, DETAIL A OF ICA-D206-642 REV. 4.

A	NEW ISSUE	AJS	11.11.02
REV.	DESCRIPTION	BY	DATE
DESIGN	AJS	<b>DART AEROSPACE USA, INC</b> KENT, WA	
DRAWN	AJS		
CHECKED	JP	DRAWING NO.	REV. A
MFG. APPR.	N/A	DSI 9583	SHEET 1 OF 1
APPROVED	140	TITLE	SCALE
DE APPR.	TH	BOLT SUBSTITUTION	NTS
DATE	11.11.02	COPYRIGHT © 2011 BY DART AEROSPACE USA, INC THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.	